




-X.5A#1
C-COMMAND ON/OFF SWITCH

1	PLOT	-S.6:C	RED 1,5
2	AMP_WK	-S.6:NO	BROWN 1,5
3	AMP_WK	-S.6:+	BROWN 1,5
4	INPUT -	-S.6:-	BLACK 1,5
5			
6			

200 mm

-S.6#1 C-COMMAND ON/OFF SWITCH

RED 1,5	-X.5A:1	PLOT	C
BROWN 1,5	-X.5A:2	AMP_WK	NO
			NC
BROWN 1,5	-X.5A:3	AMP_WK	+
BLACK 1,5	-X.5A:4	INPUT -	-



-X5A#2
C-COMMAND ON/OFF SWITCH POWER CABLE

1	PLOT	A1	RED 1,5
2	C-COMMAND WK	A1	BROWN 1,5
3	JUMP WK	-X5A:2 -X5A:6	BROWN 1,5
4	INPUT -	A1	BLACK 1,5
5			
6	AMP_WK	A1	BROWN 1,5

800 mm

-A1

Rød kabel = + inn
Sort kabel = jord
Brun kabel = til plotter / forsterker